4-Way Switch

2-Wire Romex
with Ground
(i.e. 12-2)

4-Way Switch

3-Way Switch

Input

Output

3-Way Switch

POWER SOURCE
2-Wire Romex with
Ground
(i.e. 12-2)

© www.BuildMyOwnCabin.com

3-Wire Romex
with Ground
(i.e. 12-3)